

Micro Positioning Systems with Piezo Inertial Drives

- Piezo inertial drive with lowest hysteresis
- Reached position will be held without current
- Long lifetime
- Variable step width
 - open loop about 200 nm
 - closed loop about 50 nm
- High pushing or blocking force
- No limit switches necessary
- Ultra compact dimensions possible
- Customized solutions as
 - ultra high vacuum uses
 - ultra low temperature uses
 - ultracompact drives
- Compact hand-held controller with
 - battery- or power supply operation
 - RS 232 Interface
- Compact USB controller with
 - USB voltage operation
 - USB - Interface



Hand-held controller CN 30



Miniature translation stage MS 30



Miniature translation stage MS 30; preparation for vacuum with linear measuring system



Customized development (positioning of an aperture in vacuum)



Monomode Coupler MK 25



Compact XYZ-positioner MX 25

Table of contents of the delivery program

	Page
1. Linear positioning systems with piezo inertial drives	
1.1 Miniature Monomode Coupler MK 25	2
1.2 Linear positioners for one dimension	
1.2.1 Miniature Positioning Stage MS 15	4
1.2.1 Miniature Positioning Stage MS 30	6
1.2.2 Miniature Positioning Stage MS 38 with free aperture	8
1.2.3 Positioning Stage ML 17 for ultra low temperatures	10
1.3 Linear positioners for three dimensions	
1.3.1 Miniature Positioners MX 25 and MX 35	12
2. Tilting systems with piezo inertial drives	
2.1 Mirror tilting stage MT 25	14
3. Position sensors for piezo inertial drives	
3.1 Position Sensor PS 30 for Miniature Positioning Stage MS 30	16
4. Motor Controllers	
4.1 Controller for piezo inertial drives	
4.1.1 Handheld controller CN 30 for piezo inertial drives	18
4.1.2 USB – Controller CU 30 for piezo inertial drives	19
4.2 Connecting cables for linear positioning systems	20
4.3 Autonomous controller CD 85 for DC-Motors	21
4.4 Autonomous controller CS 85 for stepper motors	23
5. Customized Items	
5.1 Linear measuring stage MS 30 with linear measuring system and vacuum	25
5.2 Motorized aperture for REM	25
5.3 XYZ – positioner for ultra low temperature microscope	25
5.4 Monomode positioner with MX 25	25

MK 25

Miniature Monomode Coupler MK 25 with piezo electric inertial motor



Technical Data

Travel:	2 mm in xyz
Max. speed:	2 mm/s (depends on controller)
Optical height:	20 mm
Mass:	58 g

Resolution (calculated)

Single step	~ 200 nm
1/16-step (with controller CU 30)	~ 15 nm

Half step	~ 100 nm
Double step (with controller CN 30)	~ 400 nm

Lens type

Type A:	
Numerical aperture	0.40
Clear aperture	3.7 mm
Focal length	4.60 (670 nm) 4.64 (785 nm)

Type B:	
Numerical aperture	0.38
Clear aperture	2.5 mm

Specifications

- Piezo driven step motor with low hysteresis
- holds reached position without current
- aspherical lenses with different NA
- optical height 20 mm
- 2 mm travel in xyz
- different fibre couplers
- step width about 200 nm
- positioning accuracy better than 100 nm
- velocity up to 0.5 mm/s
- CNC-machined aluminium body
- no limit switches necessary
- vacuum preparation optionally
- customized designs possible
- driven by hand-held (CN.030.0001)
or USB controller (CU.030.xx0x)


Application Examples


- Micro-/Nano Technology
- Bio Technology
- Microscopy
- Telecommunication
- Metrology
- R & D

Miniature Monomode- Coupler MK 25

Part no.

MK.025.1□□□



Dimensions of the Monomode Coupler MK 25

MS 15

Ultra small Miniature Translation Stages with piezo electric inertial drive



Specifications

- Piezo driven step motor with low hysteresis
- holds reached position without current
- step width about 15 nm (depends on controller)
- positioning accuracy better than 50 nm
- velocity up to 1.5 mm/s (depends on controller)
- travel 3.5 mm
- xy or xyz combinations
- CNC-machined aluminium body
- precision ball bearing guides
- no limit switches necessary
- vacuum preparation optionally
- customized designs possible
- driven by hand-held (CN.030.0001) or USB controller (CU.030.xx0x)
- connection cable CK.030.1003 recommended

Technical Data

Travel:	3.5 mm
Max. speed:	1.5 mm/s (depends on controller)
Mass:	6 g

Load characteristics

Max. load	
M_x, M_y, M_z	0.4 Nm
F_x (blocking force)	4.5 (5) N
F_y, F_z	20 N

Resolution (calculated)

Single step	~ 300 nm
1/16-step	~ 20 nm
(with controller CU 30)	

Half step	~ 150 nm
Double step	~ 600 nm
(with controller CN 30)	

Guidance accuracy (without load)

Yaw angle	< 20 arc sec
Pitch angle	< 60 arc sec
Vertical deviation	< 1 μ m
Lateral deviation	< 2 μ m

Application Examples




- Micro-/Nano Technology
- Bio Technology
- Microscopy
- Quality Control
- Metrology
- R & D

Miniature Translation Stage MS 15

Part no.

MS.015.04□□

	0	6	9
Vacuum	no	10^{-6}	10^{-9}
	0	2	3
Mounting	x	xy (not removable)	xyz

MS 15, 3.5 mm travel**Dimensions for xy – combination (not removable)****Dimensions for xyz – combination (xy – combination not removable)**

MS 30**Miniature Translation Stages
with piezo electric inertial drive****Specifications**

- Piezo driven step motor with low hysteresis
- holds reached position without current
- step width about 15 nm (depends on controller)
- positioning accuracy better than 50 nm
- velocity up to 2 mm/s (depends on controller)
- travels up to 48 mm
- open- or closed loop-application
- xy or xyz combinations
- CNC-machined aluminium body
- precision ball bearing guides
- no limit switches necessary
- vacuum preparation optionally
- customized designs possible
- driven by hand-held (CN.030.0001)
or USB controller (CU.030.xx0x)

Application Examples

- Micro-/Nano Technology
- Bio Technology
- Microscopy
- Quality Control
- Metrology
- R & D

Technical Data

Travel:	8, 18 or 30 mm
Max. speed:	2 mm/s (depends on controller)
Mass:	32, 38 or 54 g

Load characteristics

Max. load	
M_x, M_y, M_z	0.5 Nm
F_x (blocking force)	4.5 (5) N
F_y, F_z	30 N

Resolution (calculated)

Single step	~ 200 nm
1/16-step	~ 15 nm
(with controller CU 30)	


Half step	~ 100 nm
Double step	~ 400 nm
(with controller CN 30)	

Guidance accuracy (without load)


For 8 mm travel:	
Yaw angle	< 20 arc sec
Pitch angle	< 60 arc sec
Vertical deviation	< 1 μ m
Lateral deviation	< 2 μ m

**Miniature Translation
Stage MS 30****Part no.****MS.030.□□□□**

	08	18	30
Travel	8 mm	18 mm	30 mm
	0	6	9
Vacuum	no	10 ⁻⁶	10 ⁻⁹
	0	1	
Measuring-system	without	with (please specify with sensor)	

MS 30, 8 mm travel**MS 30, 18 and 30 mm travel**

Travel	A	B	C	D
18	40	33	10	15
30	52	45	16	21



MS 38

Miniature Translation Stages with free opening dia 10 mm and piezo electric inertial drive



Specifications

- Piezo driven step motor with low hysteresis
- holds reached position without current
- step width about 15 nm (depends on controller)
- positioning accuracy better than 50 nm
- velocity up to 1.5 mm/s (depends on controller)
- travel up to 8 mm
- free opening of 10 mm (on whole travel)
- fits to optical bench systems (LINOS, OWIS aso.)
- xy or xyz combinations
- CNC-machined aluminium body
- precision ball bearing guides
- no limit switches necessary
- vacuum preparation optionally
- customized designs possible
- driven by hand-held (CN.030.0001) or USB controller (CU.030.xx0x)

Technical Data

Travel:	8 mm
Free opening	10 mm
Max. speed:	1.5 mm/s (depends on controller)
Mass:	32 g

Load characteristics

Max. load	
M_x, M_y, M_z	0.4 Nm
F_x (blocking force)	4.5 (5) N
F_y, F_z	20 N

Resolution (calculated)

Single step	~ 200 nm
1/16-step	~ 15 nm
(with controller CU 30)	

Half step	~ 100 nm
Double step	~ 400 nm
(with controller CN 30)	

Guidance accuracy (without load)

Yaw angle	< 20 arc sec
Pitch angle	< 60 arc sec
Vertical deviation	< 1 μ m
Lateral deviation	< 2 μ m


Application Examples


- Micro-/Nano Technology
- Bio Technology
- Microscopy
- Quality Control
- Metrology
- R & D

Miniature Translation Stage MS 38

Part no.

MS.038.08□0



MS 38, 8 mm travel**xy and xyz combinations**

ML 17

Miniature Translation Stages for Ultra Low Temperatures with piezo electric inertial drive



Technical Data

Travel:	5 mm
Max. speed:	1.0 mm/s (with controller CU 17 LT)
Electrical connection:	2 solder points
Mass:	25 g

Load characteristics

Max. load	
M_x	3.0 Ncm
M_y, M_z	1.5 Ncm
F_x (blocking force)	1.0 (1.5) N
F_y, F_z	1.0 N

Resolution (calculated)

Single step	
with 22 V (at 4.2 K)	~ 200 nm
with 42 V (at 4.2 K)	~ 500 nm
with 82 V (at 4.2 K)	~ 1 μ m

(with controller CU 17 LT)

Guidance accuracy (without load)


For 5 mm travel:	
Vertical deviation	< 2 μ m
Lateral deviation	< 2 μ m


Specifications

- Piezo driven step motor with low hysteresis
- holds reached position without current
- for use at ultra low temperatures up to 4 K
- step width about 200 nm
- positioning accuracy better than 1 μ m
- velocity up to 1.0 mm/s
- travels up to 5 mm
- xy or xyz combinations possible
(L-bracket ML.017.9001 for xyz needed)
- CNC-machined steel body
- precision linear bearings
- no limit switches necessary
- vacuum preparation optionally
- customized designs possible
- driven by USB controller (CU.017.0003)

Application Examples


- Cryo - applications
- Micro-/Nano Technology
- Bio Technology
- Microscopy
- Quality Control
- Metrology
- R & D



Dimensions of the ML 17**xyz – combination of ML 17**

MX 25/35

Miniature XYZ Positioners with piezo electric inertial drive



MX 25 with 2 mm travel in xyz-direction

Specifications

- Piezo driven step motor with low hysteresis
- holds position without power
- up to 10 mm travel in xyz
- full step width about 200 nm (micro stepping possible)
- positioning accuracy better than 50 nm
- velocity up to 2 mm/s (depends on controller)
- CNC-machined aluminium body
- no limit switches necessary
- vacuum preparation optionally
- customized designs possible
- driven by hand-held (CN.030.0001) or USB controller (CU.030.xx0x)

Application Examples

- Micro-/Nano Technology
- Bio Technology
- Microscopy
- Quality Control
- Metrology
- R & D

Technical Data

Travel:	
MX 25	2 mm in xyz
MX 35	10 mm in xyz
Max. speed:	2 mm/s (depends on the controller)
Mass:	
MX 25	46 g
MX 35	76 g

Load characteristics

Type of load	
M_x, M_y, M_z	0.15 Nm
F_x, F_y (jamming force)	< 2 N
F_z (jamming force)	< 3 N

Resolution (calculated)


Single step	~ 200 nm
1/16-step	~ 15 nm
(with controller CU 30)	
Half step	~ 100 nm
Double step	~ 400 nm
(with controller CN 30)	



Guidance accuracy (without load)

Vertical deviation	< 2 μ m
Lateral deviation	< 2 μ m

Miniature XYZ Positioner Part no.


MX.0□5.1□□0



Drawings of the MX 25:**Drawings of the MX 35:**

MT 25

Kinematical Mirror Tilting Stage with piezo electric inertial drive



Technical Data

Angular adjustment:	6 deg (± 3 deg)
Max. speed:	25 mrad/s (depends on controller)
Optical height:	11.5 mm (on rod) 12.5 mm (in plate)
Mirror mount:	dia. 12.7 mm (1/2 inch)
Free opening:	dia. 9 mm
Mass:	46 g

Resolution (calculated)

Single step	$\sim 14 \mu\text{rad}$
1/16 step (with controller CU 30)	$\sim 1 \mu\text{rad}$
Half step	$\sim 7 \mu\text{rad}$
Double step (with controller CN 30)	$\sim 28 \mu\text{rad}$

Specifications

- Piezo driven step motor with low hysteresis
- holds reached position without current
- optical height 11.5 mm (on rod)
- angular adjustment 6 deg (± 3 deg)
- for mirror with dia. 12.7 mm
(with mirror adapter also for larger mirrors)
- free opening of 9 mm
- solid state hinges
- step width about $14 \mu\text{rad}$
- velocity up to 25 mrad/s (> 1 deg/s)
- also usable as prism stage
- no limit switches necessary
- vacuum preparation optionally
- customized designs possible
- driven by hand-held (CN.030.0001)
or USB controller (CU.030.xx0x)


Application Examples


- Micro-/Nano Technology
- Bio Technology
- Microscopy
- Telecommunication
- Metrology
- R & D

Mirror Tilting Stage MT 25

Part no.

MT.025.0□□0



Dimensions of the Mirror Tilting Stage MT 25

PS 30**Linear Measuring System for Miniature Translation Stage MS 30**

Miniature Translation Stage MS 30, 8 mm travel with PS 30

Specifications

- measuring lengths up to 30 mm
- resolution better than 50 nm
- open- or closed loop-application
- xy combinations
- ultra high vacuum preparation optionally
- customized designs possible
- driven by USB-Controller CU 30 (CU.030.xx0x)

Technical Data

Measuring length	8, 18 or 30 mm
Mass	about 20 g

Resolution

Standard	1 μm
Premium	0.5 μm
High End	0.1 μm
Excellence	0.05 μm
(other resolutions on request)	

Scale tape

Material	Steel
Grating period	20 μm
Length of scale	measuring length + 22 mm
Reference mark	at the center of the scale
Linear expansion coefficient	$23.8 \times 10^{-6} \text{ grd}^{-1}$
Accuracy class	$\pm 1 \mu\text{m/m}$

Electrical Data


Scanning frequency	max. 400 kHz
Output signal	RS 422 with interpolation
Supply voltage	5 V DC $\pm 10\%$
Power consumption	150 mA
Cable length	1.5 m
Operating temperature	$0^\circ - 55^\circ \text{C}$
Vibration (50 – 2,000 Hz)	$< 200 \text{ ms}^{-2}$
Shock (11 ms)	$< 400 \text{ ms}^{-2}$

Application Examples

- Micro-/Nano Technology
- Bio Technology
- Microscopy
- Quality Control
- Metrology
- R & D

Linear Measuring System Part no.
PS30 for Miniature Stage MS 30**PS.030.□□□□**

	08	18	30	
Travel	8 mm	18 mm	30 mm	
	0	3	6	9
Vacuum	no	10^{-3}	10^{-6}	10^{-9}
	2	3	5	6
Resolution	1 μm	0.5 μm	0.1 μm	0.05 μm

Linear Measuring System PS 30 with adapter plate for MS 30**XYZ-arrangement with MS 30 (8 mm travel) and PS 30 (8 mm travel and 50 nm resolution)**

CN 30

Controller for Piezo Electric Inertial Motors



Specifications

- Special design for piezo driven step motor
- works with batteries or external power supply
- operates up to 3 axes
- customized designs possible
- USB-interface optionally

Technical Data

Power supply: 4 x round cell LR6
(Alkaline ~ 2000 mAh)
and
portable power supply
in: 100 – 240 V
out: 6 VDC with user-plug
Ø 5.5/2.1 mm

Operation modes: "Local" with keyboard
(current consumption ~ 20 µA)
"Remote" with RS 232-Interface
(current consumption ~6 mA incl.
LED)
change switch for both modes on
keyboard

Connections: 9pin Sub D-connector (male)
9pin Sub D-connector (female)
2pin Socket (female)

Speed modes: "Fast" (ca. 0.7 mm/s)
"Slow" ("Fast"/2)
"Single step"

Step modes: "Full step"
"Half step" ("full step"/2)
"Double step" ("full step" x 2)

RS 232-interface to the internal controller

Connection: 9pin Sub D-connector (male)
Data rate: 19200 Baud

Software for PC

- for DOS, Win 95, Win 2000, Win XP and Win NT:
executable software with action
buttons (similar to the stand-alone
keyboard)
- for use with own programs:
Borland Pascal Unit (DOS)
DLL for Windows

Mass: 340 g incl. batteries

Dimensions: 158 x 96 x 52 mm

Delivery includes: - miniature power supply
- 4 x round cell LR6
- RS 232 connecting cable

Application Examples

- Micro-/Nano Technology
- Bio Technology
- Microscopy
- Quality Control
- Metrology
- R & D

CN 30 Controller

Part no.

CN.030.0001

CU 30**USB-Controller for Piezo Electric Inertial Drives****CU 30 without sensor (for three axes)****Specifications**


- Special design for piezo driven inertial motors
- works with USB-voltage (without sensor) or an additional power supply (closed loop controller)
- applications without position sensor or closed loop
- operates up to 3 axes
- customized designs possible (interfaces or number of axes)

Technical Data

Power supply:	USB-interface (without sensor) or portable power supply (for CU 30CL) in: 100 – 240 V out: 6 VDC with user-plug
Operation:	via USB-Interface 1.1 (without sensor) via USB-Interface 2.0 (closed loop)
Connections: without sensor	1 x 9pin Sub D-connector (female) 1 x USB Type B socket (USB 1.1)
closed loop	3 x 2pin MMCX sockets (female) 3 x 9pin Sub D-connectors (female) 1 x USB Type B socket (USB 2.0)
Speed modes:	0 to 1000 (0 to ca. 1.2 mm/s) for CU 30 0 to 255 (0 to ca. 1.2 mm/s) for CU 30CL
Software for PC	- for DOS, Win 95, Win 2000, Win XP and Win NT: executable software with action buttons - for use with own programs: Borland Delphi 7.0 Unit DLL for Windows Wrapper-DLL for LabView etc.
Mass:	about 150 g (without sensor) (also closed loop for 1 axis) about 470 g (closed loop for 3 axes)
Dimensions:	
without sensor	118 x 86 x 26 mm (L x W x H)
closed loop	124 x 170 x 55 mm (L x W x H)
Delivery includes:	USB connecting cable (CK.030.USB0) power supply (for 3 axes closed loop)

Application Examples

- Micro-/Nano Technology
- Bio Technology
- Microscopy
- Quality Control
- Metrology
- R & D





CU 30 closed loop (for three axes)


CK 25/30**Connecting Cables for Piezo Electric Inertial Drives**

Part-no.	Description	Connections	Length
CK.025.0002	connecting cable for 1 x MT 25 (standard)	9pin Sub D-connector (male) to 3pin inline plug	1 m
CK.025.0003	connecting cable for 1 x MK 25 or 1 x MX 25/35 (standard)	9pin Sub D-connector (male) to 4pin inline plug	1 m
CK.025.1002	connecting cable for 1 x MT 25 (open wire)	9pin Sub D-connector (male) to 3 open wires	1 m
CK.025.1003	connecting cable for 1 x MK 25 or 1 x MX 25/35 (open wire)	9pin Sub D-connector (male) to 4 open wires	1 m
CK.025.1092	vacuum connecting cable for 1 x MT 25 (open wire)	open wire to 3pin inline plug	1 m
CK.025.1093	vacuum connecting cable for 1 x MK 25 or 1 x MX 25/35 (open wire)	open wire to 4pin inline plug	1 m
CK.030.0001	connecting cable for 1 x MS 30 (for closed loop controller CU 30 CL)	1 MMCX-plug to 1 MMCX-plug	1 m
CK.030.0003	connecting cable for up to 3 x MS 30 (standard)	9pin Sub D-connector (male) to 3 MMCX-plugs	1 m
CK.030.1003	connecting cable for up to 3 x MS 30 (open wire)	9pin Sub D-connector (male) to 3 open wires	1 m
CK.030.1091	vacuum connecting cable for 1 x MS 30 (open wire)	open wire to 1 MMCX-plug (up to 10^{-9} mbar)	1 m
CK.030.USB0	RS 232 – USB Transformer (only applicable with CN 30)	9pin Sub D-connector (male) to USB A – plug	1 m
CK.030.USB0	USB connecting cable	USB A – to USB B connectors	1.8 m

For vacuum connections please ask with detailed technical specifications.

CD 85

Controller for Servo Motors



Technical Data


No. of motors:	1 to 4 motors
Types of motors:	brushed or brushless servo
Encoder:	incremental
Types of profiles:	trapezoidal, s-curve, velocity profile, electrical gear, closed curves
Contr. commands:	user friendly and self-instructional commands and parameters
Electronical gear:	master encoder selectable, slave-axis selectable, factor "in motion" alterable
Outline buffer:	any outline with up to 65,000 points programmable
Control parameter:	PID-portion, acceleration/velocity parameter changeable during motion
Monitoring functions:	error limit and position error window selectable, comparator function, simultaneous tracing of different parameters during motion
Inputs per axis:	Encoder signals A, B, Index, Home, End+, End-
Free inputs:	16 inputs, protected against misconnection, short-circuit proof
Free outputs:	16 outputs
Status/Error display:	6 LED
Interfaces:	RS 232, CAN-Bus (standard CAN 2.0B)
Supply voltage:	24 V


Specifications

- compact design, only 146 x 85 x 55 mm
- for up to 4 motors with 100 Watts
- power supply 24 Volts
- I/O card with 16 channels optionally

Application Examples


- Motion control in
- Bio Technology
 - Microscopy
 - Quality Control
 - Metrology
 - R & D



Dimensions:

CS 85

Controller for Stepper Motors



Technical Data

No. of motors:	1 to 4 motors
Types of motors:	stepper or micro stepper motors
Encoder:	incremental
Types of profiles:	trapezoidal, s-curve, velocity profile, electrical gear, closed curves
Contr. commands:	user friendly and self-instructional commands and parameters
Electronical gear:	master encoder selectable, slave-axis selectable, factor "in motion" alterable
Outline buffer:	any outline with up to 65,000 points programmable
Control parameter:	PID-portion, acceleration/velocity parameter changeable during motion
Monitoring functions:	error limit and position error window selectable, comparator function, simultaneous tracing of different parameters during motion
Inputs per axis:	Encoder signals A, B, Index, Home, End+, End-
Free inputs:	16 inputs, protected against misconnection, short-circuit proof
Free outputs:	16 outputs
Status/Error display:	6 LED
Interfaces:	RS 232, CAN-Bus (standard CAN 2.0B)
Supply voltage:	24 V

Specifications


- compact design, only 146 x 85 x 55 mm
- for up to 4 motors with 100 Watts
- power supply 24 Volts
- I/O card with 16 channels optionally


Application Examples

- Motion control in
- Bio Technology
 - Microscopy
 - Quality Control
 - Metrology
 - R & D

Controller for Stepper Motors Part no.


CS.085.□00□



Dimensions:

Customized items of the mechOnics ag

Linear measuring stage MS 30 with linear measuring system and vacuum preparation




MS 30 with

- 8 mm travel
- vacuum preparation for 10^{-6} mbar

Linear measuring system PS 30 with

- grating period $20\text{ }\mu\text{m}$
- measuring increments $0.1\text{ }\mu\text{m}$
- vacuum preparation for 10^{-6} mbar

Motorized aperture for REM



Linear positioner for an aperture with


- 7 mm travel in x – direction
- 1 mm travel in y – direction
- positioning accuracy better $1\text{ }\mu\text{m}$
- vacuum preparation for 10^{-6} mbar
- nonmagnetic materials

XYZ – Positioner for ultra low temperature microscope



- 3 mm travel in xyz
- About 250 nm step width
- Working temperature 4.2K
- vacuum preparation for 10^{-6} mbar
- Compact design

XYZ – Positioner MX 25 as Fiberpositioner



XYZ – Positioner MX 25 with

- 2 mm travel
- About 200 nm step width
- Velocity about 0.5 mm
- On profile rail with optical height 40 mm